




Replacement Float



SA91-60

For Installation on Series 93/193 and
Series 94/194 Pump Controller/LWCO



WARNING



- Before using this product read and understand instructions.



- Save these instructions for future reference.



- All work must be performed by qualified personnel trained in the proper application, installation, and maintenance of plumbing, steam, and electrical equipment and/or systems in accordance with all applicable codes and ordinances.




Failure to follow this warning could cause property damage, personal injury or death.



STEP 1 - Removal and Replacement Float

- a. Turn power off to boiler and all controls. Allow boiler to cool to 80°F (27°C) and reduce the pressure to 0 psi (0 bar).

Drain water in the boiler to a level that is below the float chamber.




CAUTION

There may be more than one source of power to the boiler.

b. Remove Head Assembly


- Remove two screws (A) and lift off switch cover.
- Identify **terminal connections** for rewiring and then disconnect all wires from **terminal panels**.
- Remove two screws (B) and lift off **conduit fitting**. Leave wires in conduit for later reconnection.
- Remove head bolts (C). There are eight (8) on Series 93/193 and ten (10) on Series 94/194. Carefully remove **head assembly** from **control body**.
- Carefully place **head assembly** in vice where replacement work can be performed more conveniently.



c. Remove and Replace Float

- Place open end of adjustable wrench on square section of float arm (D) to keep it from turning.
- Unscrew **float ball** from arm.
- Screw new **float ball** onto float arm rod (E), holding square section of float arm nut (D) with wrench and tighten securely.


IMPORTANT: Inspect condition of float arm rod and float arm springs. If these are damaged or bent, the entire head assembly will need to be replaced.



d. Prepare Flange Surfaces


Scrape and clean flange surface on control body and control head.

IMPORTANT: Care must be taken not to damage flange surfaces. Nicks, scrapes or gouges may cause the flange to leak when in service.



e. Replace Head Assembly

- Slide flange gasket (150-14 for Series 93/193 units and 92-68 for Series 94/194 units) over float ball and float stop plate.
- Insert head assembly by carefully guiding float ball into control body.
- Align Gasket and install head bolts (C).
- Using a torque wrench, tighten head bolts in an alternating star pattern. Tighten to 14-20 ft•lbs for Series 93 models. Tighten to 17-21 ft•lbs for Series 94 models.
- Install conduit fitting with attached wires and secure with two screws (B).
- Reconnect wiring to terminal panels in exactly the same position as removed.
- Replace switch cover and fasten with two screws (A).



STEP 2 - Testing

- Dimensions shown are typical.
- The following testing procedure is only meant to serve as a verification of proper operating sequence.

a. Turn on power to boiler and pump circuits.

With the boiler empty, the pump should turn on (5 or 5-M switch models) or the valve open (7B or 7B-M switch models). The burner should remain off and boiler should begin to fill with water.

CAUTION

Immediately turn off all power if the burner turns on with no water in the gauge glass. Investigate further before continuing procedure.

b. For Automatic Reset Models

When water level in the gauge glass is approximately 1 3/8" (35mm) above the horizontal cast line, the burner should turn on.

For Manual Reset Models

When water level in the gauge glass is approximately 1 3/8" (35mm) above the horizontal cast line, press the manual reset button and the burner should turn on.

c. For 5 or 5-M Switch Models

When water level in the gauge glass is approximately 2 1/8" (54mm) above the horizontal cast line, the pump should turn off.

For 7B or 7B-M Switch Models

When water level in the gauge glass is approximately 2 11/16" (68mm) above the horizontal cast line, the valve should be closed.

CAUTION

If pump does not turn off or valve close, turn off water supply to boiler. Investigate further before continuing procedure.

- d. With the water in the boiler at its normal level and burner on, SLOWLY open the blow-down valve until it is fully open. As the water level in the gauge glass begins to drop, verify that the following occurs.

For 5 or 5-M Switch Models

When water level drops to approximately 1 1/8" (29mm) above the horizontal cast line, the pump should turn on.

When water level drops to the horizontal cast line, the burner should turn off.

For 7B or 7B-M Switch Models

As the water level drops, the valve should begin to open.

When the water level drops to approximately 7/8" (22mm) above the horizontal cast line, the valve should be full open.

When the water level drops to the horizontal cast line, the burner should turn off.

- e. Close the blow-down valve after burner turns off and restore water level to normal operating level.
- f. Repeat testing procedure several times to ensure proper operation of control.
- g. After testing and verification of control operation, the boiler can be returned to service.

McDonnell & Miller




ITT Industries
Engineered for life



Recommended Maintenance

WARNING



- Before using product read and understand the installation instructions.
- Save the installation instructions and these maintenance and replacement instructions for future reference.



- All work must be performed by qualified personnel trained in the proper application, installation, inspection, and maintenance of HVAC systems in accordance with all applicable codes and ordinances.
- To prevent electrical shock, do not touch or make contact with probe ends while the system is energized or activated.



- When flushing control (blow down), hot water and steam will flow out. To prevent serious personal injury, connect a drain pipe to the control opening to avoid exposure to steam discharge.

Failure to follow this warning could cause property damage, personal injury or death.

Inspect all controls annually, and replace, repair, or clean, as needed. All chambered units are to be blown down per manufacturers instructions and local code requirements. These requirements are to be determined by the local service company, and are based on water quality

and system operation variables. Refer to the installation instructions provided with the product for specific assembly and test procedures.

McDonnell & Miller products must also be maintained in accordance with the following ASME Code.

ASME Boiler and Pressure Vessel Code - Section VI Paragraph 7.07 G

Low-Water Fuel Cutoff and Water Feeder Maintenance. Low-water fuel cutoffs and water feeders should be dismantled annually, by qualified personnel, to the extent necessary to insure freedom from obstructions and proper functioning of the working parts. Inspect connecting lines to boiler for accumulation of mud, scale, etc., and clean as required. Examine all visible wiring for brittle or worn insulation and make sure electrical contacts are clean

and that they function properly. Give special attention to solder joints on bellows and float when this type of control is used. Check float for evidence of collapse and check mercury bulb (where applicable) for mercury separation or discoloration. Do not attempt to repair mechanisms in the field. Complete replacement mechanisms, including necessary gaskets and installation instructions are available from the manufacturer. After reassembly, test as per 7.05H.

Recommended Replacement Intervals

IMPORTANT

- Product repairs made with non-McDonnell & Miller parts will invalidate our warranty as well as any agency recognitions. Without this recognition the product would no longer be eligible for use in listed end-use equipment and may not meet local code requirements.
- Previously used controls should never be installed on a new system. Always install new controls on a new boiler or system.
- A more frequent replacement interval may be necessary based on the condition of the unit at time of inspection. ITT McDonnell & Miller's warranty is one (1) year from date of installation or two (2) years from the date of manufacture.
- Use of water treatment can diminish product life. In such cases, components should be replaced on a more frequent basis.
- Visually inspect the inside of the float chamber during the annual inspection. Partial disassembly may be required.

Recommended Replacement Intervals (continued)

| Product | Series | Recommended Maintenance | Recommended Replacement Interval (Maximum) |
|--|--|---|--|
| Low Water Cut-Offs | 150, 150E, 157, 158, 159, 150S, 157S, 158S, 159S | Blow down and test daily inspect annually. | 15 years |
| | 69, 169, 269, 369, 469 | Inspect and test annually. | 10 years |
| | 67, 767 70, 70-B | Blow down weekly. Inspect and test annually. | 10 years |
| | 61, 63, 64, 764 | Blow down weekly. Inspect and test annually. | 10 years |
| | 42, 42S | Blow down daily. Inspect and test annually. | 10 years |
| | 93, 94, 193, 194 | Blow down and test daily. Inspect and test annually. | 15 years |
| | 750, PS-800, PS-850, RB-120, RB-122 | Inspect and test annually. | 15 years |
| | RB-24 | Inspect and test annually. | 10 years |
| Water Feeders | WF2/Uni-Match® | Inspect and test annually. Replace filter annually. | 10 years |
| | 101-A | Inspect, test, and replace cartridge valve annually. | 10 years |
| | 21, 221, 25-A, 51-S, 53, 851-S, 3155 | Inspect and test annually. | 15 years |
| | 47, 51, 247, 847, 551-S, 851 | Blow down weekly. Inspect and replace cartridge valve annually. | 10 years |
| Liquid Level Controls | LPC-2000, PCH, PCL, PFC, VFS | Inspect and test annually. | 15 years |
| | 18, 18-SS, 27-W, 118 | Inspect and test annually. | 5 years |
| Replacement Blow Down Valves | 14-B | Inspect and test annually. | 10 years |
| | 14 | Replace with 14-B blow down valve. | 3 years |
| Replacement Probes | 750-PA, PS-800, PS-850, RB-120, PCH, PCL, RB-122 | Inspect annually. | 10 years |
| Replacement Head Mechanisms for Commercial/Industrial Applications | 25-A, 42, 42S, 51, 51-S, 53, 61, 63, 64, 67, 70, 93, 94, 150, 150S, 150E, 157, 157S, 193, 194 | Inspect and test annually. | 5 years |

McDonnell & Miller



ITT Industries
Engineered for life